


PRECAST, PRESTRESSED COLUMNS

Fig. 2.6.1 Design strength interaction curves for precast, prestressed concrete columns

Criteria

1. Minimum prestress = 225 psi
2. All strand assumed 1/2 in. diameter,
 $f_{pu} = 270$ ksi
3. Curves shown for partial development of strand near member end where $f_{ps} \approx f_{se}$
4. Horizontal portion of curve is the maximum for tied columns = $0.80\phi P_o$.
5. $\phi = 0.9$ for $\phi P_n = 0$
0.7 for $\phi P_n \geq 0.10 f'_c A_g$
Varies from 0.9 to 0.7 for points between



Use of curves

1. Enter at left with applied factored axial load, P_u
2. Enter at bottom with applied magnified factored moment, δM_u
3. Intersection point must be to the left of curve indicating required concrete strength.

Notation

ϕP_n	= Design axial strength
ϕM_n	= Design flexural strength
ϕP_o	= Design axial strength at zero eccentricity
A_g	= Gross area of the column
δ	= Moment magnifier (Sect. 10.11, ACI 318-89)

